

Sheet1

<b>FUNC</b>	<b>MCU PIN</b>	<b>Alt FUNC</b>	<b>FUNC</b>	<b>MCU PIN</b>	<b>Alt FUNC</b>
INJ1	PE6		MOSI	PB15	KNOCK
INJ2	PE5		MISO	PB14	KNOCK
INJ3	PD7		SCK	PB13	KNOCK
INJ4	PC13		CS	PB0	KNOCK
INJ5	PE3		INTOUT	PC0	KNOCK
INJ6	PE4		INT/HLD	PB11	KNOCK
IGN1	PC7				
IGN2	PE14				
IGN3	PC9				
IGN4	PE12				
IGN5	PE8				
IGN6	PE10				
CRK	PA5				
CAM	PC6				
O2HTR	PB3				
IDLE	PD3				
VANOS	PE2	BOOST			
FuelPump	PB9				
FAN	PD5				
ECU RLY	PB8				
AC RLY	PD8				
CLT	PC2				
IAT	PC1				
MAF	PA0	"MAP"			
OXY2	PA1				
BARO	PA4				
MAP	PA3				
TPS	PC3				
BATT	PC4				
OXY1	PC5				
Acreq	PA2				
AcprSW	PE13				
VSS	PE9				
RPMout	PB7				
Tiout	PD9				
FACTreset	PD6				
CANtx	PB6				
CANrx	PB12				
Tx	PC10				
Rx	PC11				