

GENERAL

For engine harness, consult applicable ENGINE MANAGEMENT SYSTEM (EMS) subsection.

ACRONYMS

ACRONYM	DESCRIPTION
Backup	Reverse beeper connectors
Backup_Alarm	Reverse beeper
BN	Battery negative
BN_Engine	Engine ground
BP	Battery positive
BRK	Brake light switch
CL	Cluster

ACRONYM	DESCRIPTION
CL_K	Cluster keypad
DC	Accessory
DESS	DESS key
DLC	Diagnostic connector
DPS	Dynamic power steering
ECM_B	Electronic Control Module connector B
FP	Fuel pump
FT	Cooling fan

219101007-014